


Century Plus

Traditional-Style Century Plus Handpiece Control Kits

38.0631.00 Unitized

38.0375.00 Individual w/holder



- For Cascade handpiece position
- Includes control block, valve, tie bolts, gasket, and hardware

Continental-Style Century Plus Handpiece Control Kits

38.0638.00 Continental

39.1054.00 Whip only



- For Cascade handpiece position
- Includes control block, valve, tie bolts, whip assembly, gasket, and hardware

Pins For Continental Whip

39.1050.00 Short pin

39.1051.00 Long pin



- Short pin used on outer sides of end whips
- Long pin used between whips

Tie Bolt Kit

38.0504.07 3 blocks

38.0504.08 4 blocks


38.0504.09 5 blocks



- Includes (2) bolts, (2) washers, and (2) nuts

Dry Block Conversion Kit

38.0648.00



- Black base
- Contains (2) plugs (one water, one check valve)

Century Plus Control Block Service Kit

38.0537.01 Service Kit



- Includes cartridges, gaskets, stem, diaphragms, cap assembly, actuator, washers, spring, and screws
- Order IOLS diaphragm for systems that also include a Fiber-optic Light Source (75.0911.01)

Continental Whip Spring Washer Kit

90.0446.00 (10)



- Concave side of washer faces the whip

Continental Whip Tension Springs

013.015.00 Red 3 lb. spring

013.027.00 Green 4 lb. spring



- Red 3 lb. spring is standard on Cascade
- Green 4 lb. spring used for greater return pull on whip arm

Radius Delivery System Coolant Extension Knob

83.0217.00 Coolant Extension Knob



- Use if existing knobs are too short