Assistant's Holders


Assistant's Holder

99.0528.01 Holder assembly

99.0540.01 Clamp only

99.0550.01 Holder and screws

007.051.00 Screw



Extended Assistant's Arm Setscrew

007.043.00



- · Adjusts tension on the holder on the extended assistant's arm
- . For Performer and Vac Back 1020

Universal Holder Assembly with Single Bracket

99.0020.01 Gray assembly



. For mounting to wall, cabinet, or similar surface