

Upholstery Screws, Headrest Knobs, and Glide Bars

DECADE AND CASCADE UPHOLSTERY SCREWS BY MODEL	PART NUMBER	PRICE
Decade		
Armrest (requires 3)	005.123.01	
Seat (requires 4)	61.2606.00	
Headrest	001.157.00	
Cascade		
Armrest	001.184.00	
Seat (requires 4)	61.2606.00	
Headrest	001.157.00	

Performer Upholstery Kits and Screws

005.155.00 Seat, each

61.2767.00 Backrest, each



- For mounting seat upholstery to frame
- Requires 4



- For mounting narrow or contoured backrest upholstery to frame
- Requires 4

A-dec 300 Double Articulating headrest knob Kit

90.1221.00



- Includes necessary hardware

A-dec 511 Glide Bar bracket kit

99.0719.00



- Includes necessary hardware

Sliding Wedge for Glide Bar Tension

61.1569.00



- Wear pad wedge for Cascade 1040
Decade 1221, 1021, 1020
Decade 1015/1010
Performer III

Headrest Locking Knob

61.1232.01 Surf 4

61.1232.02 Gray 3




- For Cascade, Decade, and Performer III double-articulating headrest (61.2285.00)
- For Decade single-articulating headrest (61.1227.00 and 61.1548.00)

Articulating Headrest Handle

61.1553.00 Handle

61.1551.00 Locking nut



- For double-articulating headrest
- Surf
- Replacing both handle and locking nut recommended