

## Chair Solenoids and Hydraulic Oil

### A-dec 300 and 400 Chair Solenoid Assembly

90.1225.00 Solenoid



• 21.6 VDC

### A-dec 511 chair hydraulic Solenoid Kits

90.1070.00 Black wires, 100-120V

90.1071.00 Red wires, 220-240V



### Priority Chair Solenoids

60.0601.00 White, 24VDC



- 24 VDC
- O-ring packages:  
For two-piece block (035.041.02)  
For one-piece block (030.015.02)

### Cascade, Decade, Performer III, and Positioner Chair Solenoids

61.1335.00 Yellow wires, 100V

61.1336.00 Black wires, 120V

61.1337.00 Red wires, 240V



- O-ring packages:  
For two-piece block (035.041.02)  
For one-piece block (030.015.02)

### Hydraulic Oil

61.0197.00



- Hydraulic oil to add to all A-dec hydraulic chairs
- Includes noise eliminating additive
- 1 pint (16 ounces)

### Flow Adjustment Screw

61.0460.00 Screw with O-ring

030.004.02 O-ring (10)



- For hydraulic manifold on all chairs
- Flow adjustment screw with O-ring

### Truss Head Slot Screw Button Head Socket Screw

001.002.01 Truss (5)

002.118.02 Button (5)



Truss



Button

- Use on all two piece hydraulic manifolds to retain flow adjustment screws
- #2-56 x 1/8
- Use on all one piece hydraulic manifolds to retain flow adjustment screws
- 4-40 x 3/16