

# Chair Limit Switches and Position Sensor

## Limit Switch

044.184.01



- Base up function for:  
Cascade 1040  
Decade 1020/1021  
Decade 1010/1011  
Positioner 1030  
Priority 1005  
Performer III
- Back up function for:  
Positioner 1030  
Priority 1005
- Chair stop function for:  
Decade 1020/1021  
Positioner 1030  
Priority 1005

## Limit Switch

61.2065.00



- Back up function for:  
Cascade 1040

## Limit Switch


044.183.00



- Chair stop function for:  
Cascade 1040,  
Decade 1021 after June 1998,  
and Performer I and II

## Limit Switch


044.184.00



- Base up and base down  
function for: Performer I and II
- Back up function for:  
Decade 1020/1021  
Decade 1010/1011  
Performer III

## Limit Switch

61.2415.00



- Back up function for:  
Performer I only

## A-dec 500 Positioning Sensor Kit

90.1069.00 Position sensor kit



- For base or back positioning  
A-dec 500 chairs

## Stop Plate Switch Replacement Kit

90.1095.00 Surf 4

90.1095.01 White 2



- For use with A-dec 511

## A-dec 300/400 Positioning Sensor Kit

90.1183.00 Position sensor kit