

Cart and Stool Casters and Stool Knobs

Cart Height Adjustment Knob

027.007.02 Dark Surf



- Knob to adjust height on "H-frame" adjustable height carts

Stool Height Adjustment Knob

027.035.01 Gray



- Knob to adjust height on the assistant's stool with rotating torso

Caster for U-frame Carts

16.0081.00 each



- 2" ball caster for A-dec U-frame carts
- Includes screw and washer

Stool Back Height Adjustment Knob

027.063.00 1622 stools, Surf 4

027.063.01 1622 stools, White 2

027.065.00 1601 stools, Surf 4

For stools manufactured before March 24, 2003

027.024.01 1600 stools, Gray



- Knob to adjust height on the back of the stool or the torso bar

One-Piece Casters for Carts and Stools

65.1625.03 Tile (5), Surf

65.1625.04 Tile (5), Gray 3

65.0286.02 Carpet (5), Surf

65.0286.05 Carpet (5), Gray 3



- Tile caster has plastic wheel with rubber surface for use on tile floors
- Carpet caster has all plastic wheel surface for use on carpeted floors

Caster for Carts

(beginning June 2014)

30.0861.00 Tile, Surf



Stool Back Height Adjustment Knob

027.074.00 Surf 4

027.074.01 White 2



- Use for 1601 stools manufactured after March 24, 2003
- With molded-in bolt

Caster for Oregon Cart

042.615.02 Tile, Gray 3

